

HANDLESET TEMPLATE INSTRUCTIONS

Bravura®

1. Press the two plastic “cups” completely into the cross bores of the door. The template should be vertical with the pilot holes at the bottom.
2. Ensure that the template is seated snugly on the face of the door.
3. Based on the style number of your handleset, use the guide below to select the appropriate pilot hole for drilling.
4. Mark the correct pilot hole on the door.
5. Drill a 1/8” pilot hole.
(CAUTION: This hole must be level or damage and/or rough operation can occur.)
6. Drill out the pilot with a 1/2” drill bit for the lower handleset mounting tube.

Pilot Hole	Handleset Style No.
A	913, 916, 919, 970
B	915
D	980, 990
E	971, 972, 973

